

COMPOSITE RESINWOOD WORK SURFACES

General Care and Maintenance:

Allow top to reach ambient room temperature prior to installation. It may take forty-eight (48) hours for the top to acclimate to the surrounding environment. If tops will not be installed within 48 hours they must be stored horizontally with a cover over exposed face.

If final mounting requires cutting the top, then all exposed raw wood surfaces must be re-sealed. Polyurethane is an excellent sealer for lacquered tops, while mineral oil should be used for oil finished tops. Tops and benches sent without a finish and tops that are modified in the field voids the warranty.

Lacquered tops should avoid excess amounts of water, oil and strong cleaning agents. The top should be immediately wiped clean when the surface has been exposed to such excesses. When necessary, reseal any exposed raw wood surfaces to avoid expansion and swelling caused by water and humidity. Lacquer finish tops are not considered food safe.